

ICOM INSTRUCTIONS

DESKTOP MICROPHONE


SM-20

Thank you for purchasing the **SM-20** **DESKTOP MICROPHONE**.

The **SM-20** is a unidirectional, electret microphone designed for base station operation with an Icom transceiver.

The **SM-20** cannot be used with a non-Icom transceiver since the power is supplied from the connected transceiver.

FRONT VIEW



1 FREQUENCY UP/DOWN SWITCHES [UP] / [DOWN]

Change the frequency up or down. Some transceivers do not have this function.


2 PTT SWITCH

Push to transmit, then release to receive.

3 PTT LOCK SWITCH [LOCK]

Push IN to transmit continuously, then push OUT to receive.

BOTTOM VIEW



4 MIC GAIN CONTROL [MIC GAIN]

Varies microphone output level. Use this control when the connected transceiver has no mic gain controls.


NOTE: Rotating the control too far clockwise may result in overmodulation and transmit signal distortion.

5 LOW CUT SWITCH [LOW CUT]

Cuts out low-frequency components of input voice signals.

• MICROPHONE PIN CONNECTION

The pins are shown from the cable, or rear, side of the plug.



Icom Inc.

6-9-16, Kamihigashi, Hirano-ku, Osaka 547, Japan

Count on us!

A-8097@-1EX Printed in Japan
Copyright © 1991 by Icom Inc.